 © 2016 CASIO COMPUTER CO., LTD.

Quick Reference Manual 5467

CASIO

Congratulations upon your selection of this CASIO watch.

Bluetooth® is a registered trademark or trademark of Bluetooth SIG, Inc. of the United States.

Your watch has a Mobile Link function that allows it to communicate with a Bluetooth® SMART mobile phone and adjust its time settings to match those of the mobile phone.
- This product complies with or has received approval under radio laws in various countries and geographic areas. Use of this product in an area where it does not conform to or where it has not been approved under applicable radio laws may be punishable under local laws. For details, visit http://world.casio.com/ce/BLE/.
- Use of this product inside of an aircraft is restricted by the aviation laws of each country. Be sure to obey instructions provided by flight personnel concerning use of devices such as this product.

For details about functions, go to the website below and select your language for the EQB-700.
http://support.casio.com/wat/bs/

Using the Watch


Charging

Remove the watch from your wrist and place it in a brightly lit area.
- The watch may become hot when exposed to light for charging. Take care to avoid burn injury.
- Avoid charging in locations where it is very hot.

Power Saving
- Leaving the watch in a dark location for about one week will cause all hands to stop.

Battery Alerts
- Low Battery
  Second hand jumps every two seconds (Low Battery Alert).
- Dead Battery
  All hands stopped.

General Guide



1. F/-/-/E: Battery status
2. Current time
3. R: Bluetooth standby
4. Day of the week (SU, M, T, W, T, F, S)
5. Current Dual Time
6. P/A: Dual Time p.m./a.m.
7. P-A: Current time p.m./a.m.
8. ᛒ: Bluetooth connected*


* Hold down Ⓑ for about 1.5 seconds to connect via Bluetooth.

Setting the Time


1. Rotate the crown towards you to loosen it.
2. Pull the crown out to the second click.
   • This enables the minute setting.




3. Rotate the crown to change the minute setting.
4. Press Ⓑ.
   • This enables the hour setting.
5. Rotate the crown to change the hour setting.
6. Press Ⓑ.
   • This enables the year 10's digit setting.
7. Rotate the crown to change the year 10's digit setting.



8. Press Ⓑ.
   • This enables the year 1's digit setting.
9. Rotate the crown to change the year 1's digit setting.



10. Press Ⓑ.
    • This enables the month setting.
11. Rotate the crown to change the month setting.



12. Press Ⓑ.
    • This enables the day setting.
13. Rotate the crown to change the day setting.
14. After the settings are the way you want, push the crown back in and then screw it securely into place.

Specifications

Accuracy at normal temperature	: ±15 seconds a month
Timekeeping	: Hour, minute, second; date, day of the week Calendar system: Full-auto calendar from 2000 to 2099 Others: Dual time (hour, minute; Swapping with Home Time)
Mobile Link Functions	: Auto Time Correction Time setting automatically adjusted during a fixed time period. Auto summer time switching Automatic switching between standard time and summer time. Phone finder Watch operation sounds the alert of the mobile phone. Hand position correction Data Communication Specifications Bluetooth® Frequency Band: 2440MHz-2480MHz Maximum Transmission: 0 dBm (1 mW) Communication range: 2 meters max. (depends on environment)
Other	: Power Saving; Low battery alert; Battery indicator (current battery charge level)
Power Supply	: Solar panel and one rechargeable battery
Approximate Battery Life	: 5 months Conditions • Auto time correction: 4 times/day